

型号：5289说明书	图纸编号：YGH-QM-03-
尺寸：65*49mm	版本号：A-0
材质：80g书写纸 正反印刷 风琴折	日期：2023.03.24

YUCONN Temperature and Humidity Monitor	Diagram 1. Face Icon(Air comfort indicator) 2. Temperature Display 3. Humidity Display 4. Battery Icon 5. Insulating Sheet (Pull out the battery insulation sheet before use) 6. Self-adhesive film Accessory	7. Vent hole Note: Please do not block the vent hole when installing and using the product. 8. Adhesive area 9. Battery buckle Install 1. This hygrometer can be placed on the table, suitable for office and home use. 2. Stick the glued side of adhesive pad to the humidity backside first, then stick the humidity to the wall .	Temperature 1. Temperature Range:-9.9℃~60℃ (14.2°F ~ 140°F) 2. Temperature Accuracy: ±1℃ (0~40℃) , ±2℃ (40~60℃) 3. Refresh Rate: 30 seconds 4. Temperature Resolution: 0.1°F (0.1℃) 5. If the temperature is lower than -9.9℃, display: LL °C; if higher than 60℃, display: HH℃ Humidity 1. Humidity Range: 10% ~ 99% RH 2. Temperature Accuracy: ±3%~5%RH 3. Refresh Rate: 30 seconds 4. Humidity Resolution:1%	Comfort Level <table><tr><th></th><th>Temperature <19℃</th><th>19℃≤Temperature ≤27℃</th><th>Temperature >27℃</th></tr><tr><td>Humidity<30%</td><td></td><td></td><td></td></tr><tr><td>30%≤Humidity ≤70%</td><td></td><td></td><td></td></tr><tr><td>Humidity>70%</td><td></td><td></td><td></td></tr></table> Battery Tips When the power is low, the battery icon [] will appear and remind you to replace the new battery.		Temperature <19℃	19℃≤Temperature ≤27℃	Temperature >27℃	Humidity<30%				30%≤Humidity ≤70%				Humidity>70%				Battery Replacement 1. Open the battery cover from the Battery buckle. 2. Insert or replace one CR2032 button battery into the battery compartment with correct polarity (+) and (-) as shown. 3. Close the battery cover.
	Temperature <19℃	19℃≤Temperature ≤27℃	Temperature >27℃																		
Humidity<30%																					
30%≤Humidity ≤70%																					
Humidity>70%																					
YUCONN Temperatuur- en Hygrometer	Overzicht 1. Gezicht Icoon (luchtcomfortindicator) 2. Temperatuur display 3. Luchtvochtigheid display 4. Batterij icoon 5.Isolerende plaatje (Verwijder het doorzichtige plaatje voor gebruik) 6. Zelfklevende folie Accessoire	7. Lucht gat (Let op! Blokkeer het ventilatiegat niet tijdens de installatie en het gebruik van het product) 8. Lijm gebied 9. Batterij gesp Installatie 1. Deze Hygrometer kan op tafel worden geplaatst, geschikt voor kantoor en thuis gebruik. 2. Plak eerst de gelijmde kant van het kleefkussen op de achterkant van de hygrometer en plak vervolgens de hygrometer op de muur.	Temperatuur 1. Temperatuur meetbereik:-9.9℃~60℃(14.2°F~140°F) 2. Temperatuur accuraatheid:1℃(0~40℃),2℃(40~60℃) 3. Verversjtd: 30 seconden 4. Temperatuur Resolutie: 0.1°F(0.1℃) 5. Als de temperatuur lagen is dan -9.9C, dan verschijnt LL°C;Als de temperatuur hoger is dan 60℃, dan verschijnt HHC Luchtvochtigheid 1. Vochtigheid meetbereik: 10% ~ 99% RH 2. Vochtigheid accuraatheid: 3%~5%RH 3. Verversjtd: 30 seconden 4. Temperatuur Resolutie: 1%	Comfort level <table><tr><th></th><th>Temperatuur <19℃</th><th>19℃≤Temperatuur ≤27℃</th><th>Temperatuur >27℃</th></tr><tr><td>Vochtigheid<30%</td><td></td><td></td><td></td></tr><tr><td>30%≤Vochtigheid ≤70%</td><td></td><td></td><td></td></tr><tr><td>Vochtigheid>70%</td><td></td><td></td><td></td></tr></table> Batterij Tips Wanneer de batterij bijna leeg is [], verschijnt het batterijpictogram en wordt u eraan herinnerd de batterij te vervangen.		Temperatuur <19℃	19℃≤Temperatuur ≤27℃	Temperatuur >27℃	Vochtigheid<30%				30%≤Vochtigheid ≤70%				Vochtigheid>70%				Batterij vervangen 1. Open het batterijdeksel van de batterijgesp. 2. Plaats of vervang CR2032-knoopcel batterij in het batterijvak met de juiste polariteit (+) en (-) zoals afgebeeld. 3. Sluit het batterijklepje. Yuconn Thermo-/Hygrometer Model: YCN-100 Service e-mail: info@yuconn.nl
	Temperatuur <19℃	19℃≤Temperatuur ≤27℃	Temperatuur >27℃																		
Vochtigheid<30%																					
30%≤Vochtigheid ≤70%																					
Vochtigheid>70%																					